TOP AND CONSOLE PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

GAS DRYER







FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8530052	Use & Care Guide
	8558723	Tech Sheet
2		Top
	8519251	White
	3980096	Pewter
	8519252	Biscuit
3	8299950	Harness, Main
4		Panel, Console
	8558748	Platinum
	8558751	Pewter
	8558750	Biscuit
5	3394427	Clip, Harness
6	8519271	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8−18 x 1/2
12	488886	Screw, 8−18 x 1/2
13	8519406	Bezel, Cycle
14	3936150	Connector, 7−Circuit
15	3395683	Connector, (Motor)
16	8281225	Screw, 8−18 x 1/2
17	2203186	Connector, 5−Circuit
18		Knob, Assembly
	46197020472	Platinum
	46197020742	Pewter
	46197020741	Biscuit
19		User Interface
	8558753	Platinum
	8558756	Pewter
	8558755	Biscuit
20	8561811	Button, Start
21	8561812	Button, Pause/Cancel

CABINET PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8317340	Cover, Terminal Block
2	3390814	Screw, 8−18 x 3/8
3	697776	Screw, 10−32 x 5/8 (Ground)
4		Panel, Side (R.H.)
	8519213	White
	8519217	Pewter
	8519214	Biscuit
5	3394881	Switch, Broken Belt
6	8521959	Dry Rack (Top)
7		Panel, Side (L.H.)
	8519209	White
	8519216	Pewter
	8519210	Biscuit
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12		Plug, Multivent
	697750	White
	3979261	Pewter
	3388311	Biscuit
13	3388672	Pulley Assembly
14	3978776	Bracket, Gas Pipe
15	8066120	Lever, Snap Switch
16	3394081	Wire, Belt Switch
17	8564132	Sound Panel
18	233520	Washer, Thrust
19	8283288	Wire, Jumper (Includes Illus. #41)
20	690997	Tri Ring
21	8066115	Cover−Plate
22	8529053	Ramp, Door
23	8521961	Dry Rack Support
24	693995	Screw, 8−18 x 3/8
25	8521957	Dry Rack Assembly
26	3393657	Restrainer, Belt
27	8538263	Motor Assembly 60 HZ.
28	3398948	Wire, Jumper (Broken Belt Switch)
29	3389729	Pulley 60 HZ.
30	3387610	Belt, Drive
31	8529757	Bracket, Burner
32	3387118	Bracket, Motor
33	3401401	Cord, Power
34	49026	4" − 90° Elbow
36	3395532	Exhaust Pipe & Bracket
37	3395534	Exhaust Pipe (Short)
38	3395535	Exhaust Pipe (Long)
39	3388674	Idler Bracket
41	8519323	Switch, Door
42	98129	Screw, 6−20 x 1 1/16
43	3390647	Screw, 8−18 x 1/2
44	3387242	Seal, Front Panel
45	3393008	Screw, 10−16 x 1/2
46	8519459	Clip, Toe Panel
50	8519207	Base, Cabinet
51		Front Panel (Includes Illus. 44)
	8562167	White
	8562169	Pewter
	8562168	Biscuit
52	696144	Strike, Door (2)
55	8299929	Harness, Digital Interface
56	8519273	Bracket, Control
57	8546219	Control Board
59	3400826	Screw, 8−18 x 3/4
61		Toe, Panel
	8519233	White
	3980095	Pewter
	8519234	Biscuit
62	8519219	Panel, Rear
63	692400	Nut, Push−In
64	343641	Screw, 10−16 x 1/2

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

66	279818	White
	279969	Pewter
	279925	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	3394984	Door, Lint Screen
4	3406653	Harness, Sensor
5	3394346	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3359452	Nut,3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	3402841	Lens, Drum Light
11	359625	Screw, 8−18 x 1/2
12	3388229	Clip, Exhaust Pipe
13	3390646	Screw, 8−18 x 5/16
14	8529007	Plug, Rear Bulkhead
15	693995	Screw, 8−18 x 3/8
16	3387709	Nut, 3/8−16 (L.H.)
17	8520836	Bulkhead, Rear
18	3387459	Washer, Support
19	3399509	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	3402715	Exhaust Pipe
23	3394985	Housing, Outlet
24	3401850	Harness, Gas
25	8299966	Complete Drum Assembly
26	97787	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	353424	Plug, 3−Way
29	90767	Screw, 8−18 x 3/8
30	8519221	Channel Bracket, Rear Bulkhead (2)
31	8519275	Bracket, Upper Rear Bulkhead
32	717252	Plug, 2−Way
33	3406124	Bulb, Light
34	3387223	Electrode, Sensor
35	3977373	Bracket, Drum Light
36	3403634	Socket Assembly
37	697772	Wheel, Blower
38	3403498	Connector, 3−Position
39	3394986	Spring, Lint Screen Door
40	3403499	Connector, 2−Position
41	695240	Screw, 8−18 x 1/2
42	3976615	Thermistor
43	487909	Screw, 8−15 x 1/2
44	8544362	Housing, Blower
45	8066168	Lint Duct Assembly
46	8066047	Funnel, Burner
47	3403140	Thermostat, High−Limit 205°F (96°C)
48	338906	Sensor, Radiant
49	489463	Screw, 8−18 x 5/8
51	3387230	Screw, 10−16 x 1
53	697693	Baffle, Drum
54	8519245	Bulkhead, Front
58	8299979	Grill, Outlet
59	3392519	Thermal Fuse
60	697770	Seal, Cover Plate
64	8066170	Lint, Screen

8318276 BURNER ASSEMBLY

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



8318276 BURNER ASSEMBLY

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318276	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 7/8)
6	343641	Screw, 10−16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318281	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8−18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support
Following Parts Not Illustrated		
	694572	Conversion Kit (Type (1) to Type (4) LPG).

BA−149

DOOR PARTS

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8563855	Plug, Strip
2	8559709	Door Hinge Assembly
3	342043	Screw, 10−32 x 3/8
4	9742177	Screw, 8−18 x 5/8
5	8529539	Bracket, Handle
7		Handle, Door Assembly (LH)
	8559739	Platinum
	8559743	Pewter
	8559741	Biscuit
		(Following Parts Not Included)
		Handle, Door Assembly (RH)
	8559738	Platinum
	8559742	Pewter
	8559740	Biscuit
8	3357011	Screw, 10−16 x 1/2
9		Door Assembly (Outer)
	8541574	Platinum
	3980079	Pewter
	3977873	Biscuit

Illus. No.	Part No.	DESCRIPTION
10	8546200	Door Assembly (Inner)
		(Includes Illus. 12)
11	355515	Screw, 8−18 x 11/16
12	3389441	Door Catch Assembly
14	8529540	Badge, Assembly
15		Filler Handle (LH)
	8528289	Platinum
	3980082	Pewter
	3979771	Biscuit
		(Following Parts Not Included)
		Filler Handle (RH)
	8528287	Platinum
	3980101	Pewter
	3979772	Biscuit
16		Cover−Hinge, Stationary (RH)
	8559713	Platinum
	8559719	Pewter
	8559717	Biscuit
		(Following Parts Not Included)
		Cover−Hinge Stationary (LH)
	8559712	Platinum
	8559718	Pewter
	8559716	Biscuit

Illus. No.	Part No.	DESCRIPTION
17		Cover−Hinge, Rotating
	8559722	Platinum
	8559724	Pewter
	8559723	Biscuit
18	8547091	Clip, Trim Panel
19		Trim & Clip Assembly (Lower)
	8558683	Platinum
	8558685	Pewter
	8558684	Biscuit
20		Trim & Clip Assembly (LH)
	8558687	Platinum
	8558692	Pewter
	8558690	Biscuit
21		Trim & Clip Assembly (RH)
	8558689	Platinum
	8558693	Pewter
	8558691	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PEDESTAL PARTS (NOT INCLUDED)

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8537141	Installation Instructions
	LIT8537342	Parts List
2		Drawer Front Assembly
	8537870	White
	8537871	Biscuit
	8537872	Graphite
	8537908	Pewter
	8537931	Meteorite

Illus. No.	Part No.	DESCRIPTION
3		Drawer Bin
	8537883	For Model Numbers LAB2700MQ, LAB2700MT, LAB2700MK and LAB2700ML
	8537934	For LAB2700PMT
4		Divider, Drawer (Set Of 2)
	8537875	For Model Numbers LAB2700MQ, LAB2700MT, LAB2700MK and LAB2700ML
	8537935	For LAB2700PMT

Illus. No.	Part No.	DESCRIPTION
5	8537850	Slide Assembly
6	3400111	Screw
7	8537852	Foot Assembly
8	3400639	Screw, 6−20 x 3/8
9		Cabinet (Not Serviced)
10	3400842	Screw, 8−18 x 1/2
11	8537863	Pad (4)
12	8537853	Pan, Bottom
13	9740848	Screw
14	90767	Screw

OPTIONAL PARTS (NOT INCLUDED)

For Models: GGW9250PW0, GGW9250PL0, GGW9250PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4396174	Pewter
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4396175	Pewter
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
		ACCESSORY PARTS
	8529894	Kit, Hold Down Kit, Door Reversing
	8530070	Platinum
	8530072	Pewter
	8530071	Biscuit
	8541503	Kit, Stack Assembly
	80047	Kit, Dryer Repair